

<b>SEER3000 Pro-1.0</b>	<b>37CH Mode1</b>	<b>32CH Mode2</b>	<b>DMX Value</b>	<b>Function</b>
Dimmer	1	1	0---255	Brightness--->Darkness
Dimmer FINE	2		0---255	
Strobe	3	2	0---3 4---103 104---107 108---207 208---212 213---225 226---238 239---251 252---255	Closed Slow Strobe--->Fast Strobe Open SlowPuls---->Fast Puls Open Random Slow Strobe Random Medium Strobe Random Fast Strobe Open
Color	4	3	0---7 8---14 15---21 22---29 30---36 37---44 45---51 52---59 60---6 67---74 75---81 82---89 90---96 97---104 105---111 112---119 120---126 127---127 128---191 192---255	White White + Color1 Color1 Color1 + Color2 Color2 Color2 + Color3 Color3 Color3 + Color4 Color4 Color4 + Color5 Color5 Color5 + Color6 Color6 Color6 + Color7 Color7 Color7 + Color8 Color8 Color8 + Color9 CW Rotating Slow--->Fast CCW Rotating Fast--->Slow
Cyan	5	4	0---255	EXCLUDED---->INSERTED
Magenta	6	5	0---255	EXCLUDED---->INSERTED
Yellow	7	6	0---255	EXCLUDED---->INSERTED
CTC	8	7	0---255	EXCLUDED---->INSERTED
Macro Color	9		0---255	
IRIS	10	8	0---128 129---131 132---171 172---211 212---251	MAX----->MIN Close Slow Puls---->Fast Puls Slow Puls Fast Close---->Fast Puls Fast Close Slow Puls Fast Open---->Fast Puls Fast

			252---255	Open Open
Gobo1 Select	11	9	0---10 11---20 21---30 31---40 41---50 51---60 61---70 71---80 81---100 101---120 121---140 141---160 161---180 181---200 201---220 221---237 238---255	White Gobo1 Gobo2 Gobo3 Gobo4 Gobo5 Gobo6 Gobo7 Gobo1 Shake Slow---->Fast Gobo2 Shake Slow---->Fast Gobo3 Shake Slow---->Fast Gobo4 Shake Slow---->Fast Gobo5 Shake Slow---->Fast Gobo6 Shake Slow---->Fast Gobo7 Shake Slow---->Fast CW Rotation Slow---->Fast CCW Rotation Fast---->Slow
Gobo1 Index Rotation	12	10	0---127 128---191 192---255	0° ---->360° (FINE IN 13CH) CW Rotating Slow---Fast CCW Rotation Fast---Slow
Gobo1 Index Rotation FINE	13		0---255	
Fixed Gobo Animation	14	11	0---5 6--21 22---27 28---33 34---39 40---45 46---51 52---57 58---63 64---69 70---85 86---101 102--- 117 118---133 134---149 150---165 166--- 181 182--- 197 198--- 225 226---255	White Animation Shake Slow---->Fast Gobo1 Gobo2 Gobo3 Gobo4 Gobo5 Gobo6 Gobo7 Gobo8 Gobo1Shake Slow---->-Fast Gobo2 Shake Slow---->-Fast Gobo3 Shake Slow---->Fast Gobo4 Shake Slow---->Fast Gobo5Shake Slow---->Fast Gobo6 Shake Slow---->Fast Gobo7 Shake Slow---->Fast Gobo8 Shake Slow---->Fast CW Rotation Slow---->Fast CCW Rotation Fast---->Slow

BLADE1	15	12	0---255	EXCLUDED---->INSERTED
BLADE2	16	13	0---255	EXCLUDED---->INSERTED
BLADE3	17	14	0---255	EXCLUDED---->INSERTED
BLADE4	18	15	0---255	EXCLUDED---->INSERTED
BLADE5	19	16	0---255	EXCLUDED---->INSERTED
BLADE6	20	17	0---255	EXCLUDED---->INSERTED
BLADE7	21	18	0---255	EXCLUDED---->INSERTED
BLADE8	22	19	0---255	EXCLUDED---->INSERTED
FRAMING ROTATION	23	20	0---255	Position 0° ---->90°
Prism	24	21	0---127 128---255	EXCLUDED INSERTED
PrismRotation	25	22	0---127 128---190 191---194 195---255	Position 0°-->360° CW Rotation Fast---> Slow STOP CCW Rotation Slow--->Fast
Forst	26	23	0---255	EXCLUDED----->INSERTED
Focus	27	24	0---255	
Focus FINE	28		0---255	
Zoom	29	25	0---255	
Zoom FINE	30		0---255	
PAN(X)	31	26	0---255	
PAN(X) FINE	32	27	0---255	
TILTE(Y)	33	28	0---255	
TILTE(Y) FINE	34	29	0---255	
P/T SPEED	35	30	0---128 129---170 171---211 212---255 252---255	Fastest----->Slowest SlowSpeed (1/3 MaxSpeed) MediumSpeed (1/2 MaxSpeed) Fast Speed (Fastest Speed) Darkness when moving
Lamp Control	36	31	0---32 33---64 65---96 97---128 129---160 161---193 194---225 226---255	Undefined LAMP OFF(> 3s) Undefined LAMP ON(> 3s) Undefined LOW POWER(> 3s) Undefined FULL POWER(> 3s)
Control	37	32	0---127 128---153 154---179 180---205 206---231 232---255	Undefined Undefined Undefined Undefined Undefined Reset ALL(> 3s)