

EOS-F600A	17CH Model	DMX Value	Function
Dimmer	1	0---255	Darkness----->Brightness
Strobe	2	0---7 8---65 66---71 72--127 128---133 134---189 190---195 196---250 251---255	Closed Slow Strobe--->Fast Strobe Open Slow Puslation Fast Close--->Fast Puslation Fast Close Open Fast Puslation Slow Close--->Fast Puslation Fast Close Open Random Strobe Open
Red ALL	3	0---255	Darkness----->Brightness
Green ALL	4	0---255	Darkness----->Brightness
Blue ALL	5	0---255	Darkness----->Brightness
White ALL	6	0---255	Darkness----->Brightness
Macro	7	0---10 11---22 23---33 34---44 45---55 56---66 67---77 78---88 89---99 100---110 111---121 122---132 133---143 144---255	Closed Macro1(Color Fixed) Macro2(Color Control IN MacroColor CH17) Macro3(Color Control IN MacroColor CH17) Macro4(Color Fixed) Macro5(Color Control IN MacroColor CH17) Macro6(Color Fixed) Macro7(Color Control IN MacroColor CH17) Macro8(Color Fixed) Macro9(Color Control IN MacroColor CH17) Macro10(Color Fixed) Macro11(Color Control IN MacroColor CH17) Macro12(Color Control IN MacroColor CH17) Reserved
MacroSpeed	8	0---255	Slowest--->Fastest
ZOOM	9	0---255	
ZOOM Rotation	10	0---127 128---191 192---255	0° ----->360° CW Rotation Slow---->Fast CCW Rotation Fast--->Slow
Pan	11	0---255	
Pan FINE	12	0---255	
Title	13	0---255	
Title FINE	14	0---255	
P/T Speed	15	0---255	Reserved
Control	16	0---231 232---255	Reserved Reset ALL(>3s)

MacroColor	17	0---50 51---101 102---152 153---203 204---255	RED FADE IN, GREE = 0, BLUE = 0 RED FADE OUT, GREE FADE IN, BLUE = 0 RED = 0, GREE FADE OUT, BLUE FADE IN RED FADE IN, GREE = 0, BLUE MAX RED MAX, GREE FADE IN, BLUE MAX
-------------------	-----------	--	--